

命令模式

CLS [/WAIT]

Clears the command/output area of the screen.

清空屏幕结果显示

Operation

操作

Normally, the CLS command is acted upon immediately. However if the /WAIT parameter is given and the WAIT AUTO mode is in effect, the spacebar must be pressed before screen is cleared.

正常情况下，命令 CLS 会立刻清空屏幕结果显示。然而如果加上参数/WAIT，且打开了 WAIT AUTO 模式，必须按下空格键，屏幕才会被清空。

CLS /WAIT differs from WAIT | CLS in that the latter always waits while the former is conditional as explained above.

CLS /WAIT 命令与 WAIT | CLS 命令不同，后者总是等待；而前者视情况，如上所诉。

Display Output

显示输出

Clears the screen only — no effect on disk or printer output.

只是清空屏幕结果显示，不影响储存内容和报告输出

Nondisplay Output

无显示输出

none.

无

Examples

样例

Clearing the screen immediately:

立刻清空屏幕结果显示：

CLS

Waiting (if no output device is turned on) before clearing the screen:

在清空屏幕前等待（如果没有输出设备被开启）：

CLS /WAIT