

## 命令模式

---

### HELP topic

Displays documentation for the given command on the screen.

显示指定命令的帮助说明。

### HELP

Lists all available GHS 14.00 commands on the screen.

屏幕列出所有 GHS 14.00 版本的命令。

## 参数说明

---

### topic

Any GHS command name or valid abbreviation. In addition, the following topics are available:

任何 GHS 命令或有效缩写。另外，也可以查询下面的关键词：

**CONCEPTS** - Essential concepts

-重要概念

**START** - Getting started

-启动程序

**KEYBOARD** - Keyboard operations

-键盘操作

**ERRMSG** - Error messages

-错误信息

**SIZE** - Size limits

-范围限制

**SYNTAX** - Command syntax format rules

-命令语法规则

**MAIN** - Main program parameters

-主程序参数

**PM** - Part Maker introduction and summary

-创建模型介绍和总结

**PM\_AM** - Part Maker creating appendages

-创建模型中附体结构

**PM\_TM** - Part Maker creating tanks

-写创建模型中舱室

**SE** - Section Editor

-模型修改编辑器

**SE\_MODEL** - SE essential modeling concepts

-模型编辑器概念解释

**SE\_START** - SE getting started guide

-模型编辑器向导

**SE\_REF** - SE command reference

-模型编辑器命令参考

**SE\_DISPL** - SE geometry display

-模型编辑器模型显示

**MC** - Model Converter

-模型转换

**MC\_SHC** - MC SHCP import

-SHCP 格式文件与 gf 文件转换

**MC\_DXF** - MC DXF import/export

-DXF 格式文件与 gf 文件转换

**MC\_OFE** - MC OFE import/export

-OFE 格式文件与 gf 文件转换

**MC\_IDF** - MC IDF (IMSA) import/export

-IDF(IMSA)格式文件与 gf 文件转换

**MC\_HEC** - MC HEC (Herbert) import

-HEC(Herbert)格式文件与 gf 文件转换

**MC\_PIAS** - MC PIAS import/export

-EAG 格式文件与 gf 文件转换

**MC\_SEASA** - MC SEASAFE import

-IN 格式文件与 gf 文件转换

**MC\_SHIPMO** - MC ShipmoPC export

-GF 格式文件转换为 ShipmoPC 文件

**MC\_GF** - MC GF internal conversion

-将 GF 文件的部件进行内部转换

**MC\_FIXUP** - MC Fixup Mode

-更新或修正 GF 模型

**MC\_TPF** - MC Tank Property File import

-舱室属性文件输入

**MC\_WAMIT** - MC WAMIT (GDF) export

-将 GHS 模型文件的某部件转换为 GDF 格式

**SE\_DISPL** - Section Editor on-screen display

-屏幕显示模型编辑器

**SE\_MODEL** - Section Editor modeling concepts

-模型编辑器建模概念

**SE\_REF** - Section Editor command reference

-模型编辑器命令参考

**SE\_START** - Section Editor getting started

-启动模型编辑器

**CG** - Condition Graphics

-工况图

**FLMANUAL** - Floodable Lengths user manual

-可浸长度用户手册

**GHSKOM** - GHS Communications between programs

-GHS 与其它程序的连接

**GS** - Grain Shift

-谷物移动

**HMMANUAL** - Hull Maker for barges user manual

-驳船船体建模用户手册

**LEOP** - Load Editor operation

-装载编辑器操作

**LEWOP** - Load Editor with windows operation

-装载编辑器界面操作

**LOADLEW** - Load Editor with windows LOAD command extensions

-装载编辑器界面中 LOAD 命令的拓展

**LSMANUAL** - Longitudinal Strength User Manual

-总纵强度用户手册

**MB** - Multi-Body

-多体操作

**TSMANUAL** - Tank Soundings user manual

-舱室测深用户手册

**GF** - Geometry File format

-模型文件格式

**\*** - Menu of all help topics and operations

-所有关键词操作帮助清单

## Operation

### 操作

---

When used with the topic parameter, documentation will be displayed on screen. Certain keyboard keys are active for browsing through the document as follows:

当查询关键词时，屏幕会显示文件说明。下面显示部分浏览文件时会用到的热键：

- Page Down** - Advance to the next screen-page  
-跳到下页
- Page Up** - Back up to the previous screen-page  
-回到上页
- Down Arrow** - Advance one line  
-前进一行
- Up Arrow** - Back up one line  
-后退一行
- Home** - Skip to the start of the topic  
-跳到主题的开始
- End** - Skip to the end of the topic  
-跳到主题的结尾
- Ctrl-PgDn** - Advance to the next topic  
-跳到下一个主题
- Ctrl-PgUp** - Back up to the previous topic  
-回到当前的主题
- Ctrl-Home** - Skip to the first topic  
-跳到第一个主题
- Ctrl-End** - Skip to the last topic  
-跳到最后一个主题
- F** - Search for a string in the current topic  
-在当前主题中寻找一字符
- G** - Search globally for a string in all topics  
-在所有主题中寻找一字符
- A or Enter** - Search again for next occurrence of string from F or G  
-在当前或所有主题中寻找某字符下一次的出现
- DoubleClick** - Search globally for double-clicked word  
-全局搜索所双击的单词
- Ctrl-E** - Toggle case-sensitive searching  
-转换为区分大小写搜索
- Ctrl-W** - Toggle whole-word searching  
-转换为整词搜索
- Right Click** - Display index of all available topics and options  
-显示可用到的主题索引
- Esc** - Return to the main program  
-回到主程序

When used without the topic parameter, the names of all available Main Program commands are listed in alphabetical order. The minimum abbreviations are shown in capital letters. (Macro command names are listed separately when the MACRO command is issued.)

当省略关键词时，所有的主程序可用命令按照字母顺序展列出来。可用的最小缩写会以大写字母的格式显示。（如果使用命令 MACRO，宏命令会单独展列出来。）

An acceptable alias for the HELP command is a single question mark. At start up, the F1 function key is programmed to issue a HELP command.

可用问号代替 HELP 命令。在开始时，F1 键可以使程序打开帮助菜单。

HELP \* (or right-clicking the help window) shows a complete index of topics and operations.

HELP \*或右键点击帮助窗口，可以显示所有命令和操作主题的索引。

## Display Output:

### 显示输出

---

Documentation for the given command or a list of commands is displayed on the screen only.

显示给定命令的帮助说明或屏幕显示一系列的命令。

## Nondisplay Output:

### 无显示输出

---

none.

无

## Examples

### 样例

---

Requesting a list of available commands:

显示可用的命令：

**HELP**

Requesting a clickable menu of all help topics and operations:

显示可点击的命令帮助清单：

**HELP \***

Requesting help for the LIMITS command:

解释 LIMITS 命令：

**HELP LIM**

Requesting the Part Maker section of the manual to be displayed on screen:

屏幕显示 PM 模块帮助手册:

**HELP PM**